Klark Teknik DN 30R / DN 30T Firmware Update Procedure

Requirements:

1. Download the most recent **Firmware Update Manager** from audinate.com.
   https://www.audinate.com/products/firmware-update-manager
2. Read the **Update Manager User Guide**.
   https://www.audinate.com/content/dante-firmware-update-manager-user-guide
3. Download the **firmware file** for your specific Dante device.
4. Start Firmware Update Manager app and browse for the firmware file on your PC/Mac.
5. After scanning the network, all attached compatible Dante devices will be listed and you can choose which one(s) to update by setting the tickmark.
6. Keep all selected Dante devices powered up until the completion message pops up.
7. The new firmware will be active after re-booting your respective Dante devices.
8. Connection to Ravenna/AES67 devices will require installing the RAV2SAP Connection Manager.

© Music Tribe Global Brands Ltd. All rights reserved.
All information in this document is subject to change without any further notice.