

Update of TW AUDiO Presets in LAKE-Controller

The update is necessary for all LAKE-Controllers up to version 6.7.1. In newer releases the presets are already included in the Lake Load Library.

1. Download the latest presets from TW AUDiO website.



2. Unpack the .zip-file.




3. Delete all TW AUDiO preset data from your pc.

   Please delete all module and frame presets files which are usually located in the folders: C:\Users\username\Documents\Lake\LakeController_vXXX\Modules and EQ Overlays\Lake LoadLibrary XX\Suitable for TW AUDIO loudspeakers

   and
   C:\Users\username\Documents\Lake\LakeController_vXXX\FramePresets\LoadLibrary 3.14 Frame Presets\Suitable for TW AUDIO loudspeakers

4. Copy the folders “PLM and LM series” and “PLM+ series” containing module presets in your local LAKE folder.

   The folder should be located in:
   C:\Users\username\Documents\Lake\LakeController_vXXX\Modules and EQ Overlays\Lake LoadLibrary XX\Suitable for TW AUDIO loudspeakers



5. Copy containing data from folder “Frame presets” in your local LAKE folder.

   The folder should be located in:
   C:\Users\username\Documents\Lake\LakeController_vXXX\FramePresets\LoadLibrary 3.14 Frame Presets\Suitable for TW AUDIO loudspeakers

