Midas HUB4 Firmware

Version 3.3

Fixed:

- DL8 connected to ports 2 to 4 were not reporting preamps to WING

Version 3.2

Improvements:

- Implementation of WING preamp remote control messages

Fixed:

- Talkback and routing issues

Version 3.1

Improvements:

- MASTER mode engaged by pressing PORT 1-4 button during power up
- StageConnect 16 channel-transmission to ports 1-4 in MASTER mode

Fixed:

- HUB4 not picking up DP48 enumeration when used with HD96 console

Firmware update process with SimplyPUT

1. Download and install SimplyPUT from midasconsoles.com (available for MacOS, Windows and Linux).
2. Connect the powered off HUB4 to a computer via USB.
3. Hold button 1 below "PORT 1-4 TO OUTPUTS" while turning on the HUB4 until all buttons 1 - 4 turn green.
4. Open SimplyPUT. The app will detect the device automatically.
5. Select the firmware version you want to install and click on Update.
6. Restart the HUB4 after the device's LEDs stop flashing and disconnect it from the computer.

© Music Tribe Global Brands Ltd. All rights reserved.
All information in this document is subject to change without any further notice.