TC Electronic DC30 PREAMP Firmware

Version 1.0.8 (01 Sept 2023)

Update Instructions

How to update your AMPWORX firmware?

1. Connect your AMPWORX to your computer with the included USB cable.
2. Hold down the right-side footswitch (labeled “CHANNEL”).
3. Power-on your AMPWORX and wait until the right-side LED lights green. Release the footswitch.
4. Launch the firmware updater on your computer (separate files are available for MAC and Windows).
5. The updater will recognise the connected device and display its name.
6. Click the button “Update” and wait until the progress bar reaches the end.
7. During the update, your AMPWORX will blink green and red alternatively, indicating the process is ongoing.

DO NOT remove the power from your unit while the update is in progress.

What’s New?

- Footswitch operation is now “on-press” and not “on-release”.
- Improved cabinet sim IR (impulse response) with:
  - Softer treble, naturally producing a warmer tone.
  - Subtly extended bass response for a fuller feeling.
    (These changes only affect the “CABSIM” output).
- Improved tube model, preserving the overall gain structure but smoothing their behaviour when transitioning towards saturation. This provides the more accurate “broken-in” touch sensitivity obtained after the tubes have been used for some time.

© Music Tribe Global Brands Ltd. All rights reserved.
All information in this document is subject to change without any further notice.