

M32-Series Firmware Update

Version 4.04 - (18 November 2020)

The console 4.04 firmware update offers some functional improvements and new features. The highlight of this update is the implementation of DCA-Spill. This new function offers the possibility to use the SELECT-Button of a DCA to unfold the assigned channels to the left fader bank. This update also offers some improvements for the use with the X-Touch controller and some general bugfixes.

We recommend to periodically check for new updates, for the latest features and improvements. Our development team is eager to react to customer suggestions and to amaze you with improvements and new features. Visit midasconsoles.com to download the latest firmware, install the update and enjoy the full potential of your M32.

This new M32 Firmware version contains:

New Features

- DCA-Spill (only for M32-Models with faders)
 - Press SELECT on DCA to see associated channels (flashing SELECT on DCA)
 - Hold SELECT on DCA to change DCA assignment (flashing SELECT on channels)
 - Press DCA layer button to toggle between DCA-Spill pages
 - Change left faderlayer or hold DCA layer button to disable DCA Spill (Active DCA-Spill is indicated by flashing DCA layer button)

Improvements

- Improved interoperability with X-Touch
 - Gain/Trim issue on CH 1-8
 - Issue with send pan indication when using 'sendPanFollowsLR'
- Improved Copy/Pasting of dynamic settings for MTX/ST/M

Bug Fixes

- Prevent freeze when using Snippet-Utility
- Fixed send pan LED-Ring indication when using 'sendPanFollowsLR'
- Hide folder names with non ASCII characters

Update Process:

1. Download the new console firmware from the M32 product page onto any directory of a FAT32 formatted USB thumb drive
2. Plug the USB thumb drive into the top panel USB connector
3. Open SETUP - GLOBAL on the console and select UPDATE FW in the lower left corner
4. Navigate to the directory where the firmware file is stored and install update

Alternative Update:

1. Download the new console firmware from the M32 product page at behringer.com onto the **root directory** of a FAT32 formatted USB thumb drive.
2. Plug the USB thumb drive into the top panel USB connector while the console is turned off.
3. Hold the USB View button pressed while switching the console on. While booting, the M32 will run a fully automatic firmware update, which will take 2-3 minutes longer than the regular boot sequence.
4. When no update file is available on the USB drive, or when it is corrupted, the update mode will remain active, preventing the M32 from booting regularly. Switch the console off and back on without holding the USB View button to boot the console with the existing firmware.

**Note: Midas recommends to create a console backup before installing the update.
This backup can be restored in case of data loss during the firmware update.**